Page 1 of 2 **ROWAN** Riverside Occasional Tables Made in Viet Nam Assembly Instructions info@riverside-furniture.com email: Components and Hardware List Top Shelf Α #12302 - Cocktail Table 1 pc. 1 pc. 4 pcs. Allen Head Bolt Allen Head Bolt Lock Washer Flat Washer Bracket Allen Kev 19 x 22 x 30mm Ø9 x Ø13mm Ø8 x Ø20mm 4 x 110mm Ø8 x 50mm Ø6 x 15mm 8pcs. H2 16 pcs. (H4) 8 pcs. (H3) 16 pcs. (H5) 4 pcs. (H6) 1 pc. (H1) Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. To prevent possible scratches or damage, assemble on a soft and smooth surface such as a blanket or carpet. Step 1: Attach the Brackets (H5) to the Legs (C) using the Flat Washer (H4), Lock Washer (H3) and Bolts (H2) as shown. Do not fully tighten until Step 4. $\overline{H2}$ $\overline{\mathrm{H4}}$ Step 2: Place the Top (A), upside down on a soft and smooth surface. Attach three legs to the Top (A) using the Flat washer (H4), Lock washer (H3) and Bolts (H1). Do not fully tighten Bolts until fourth Leg has been attached. H3 H1 (H6)

