



1. INSERT THE CROSSBAR INTO THE LEGS AND ALIGN THE HOLES AND SCREW THEM AS SHOW IN FIGURE "1".

2. WITH HELP TURN THE TOP UPSIDE DOWN ON A CLEAN SURFACE.

3. ALIGN THE LEG HOLE INTO THE TABLE TOP AND SCREW TIGHTLY AS SHOW IN FIGURE "2".

4. PLACE THE METAL SUPPORT AND SCREW THEM AS SHOW IN FIGURE "3"

HARDWARE	
DESCRIPTION	# PCS
ALLEN KEY 5/32"	1
JOINT CONNECTOR ALLEN BOLT 1/4" X 50	4
JOINT CONNECTOR NUT 1/4"	2
HEX BOLT 5/16" x 1"	4
HEX BOLT 5/16" x 2 1/2"	2
WASHER 5/16"	6
FLAT HEAD SCREW 8 x 1 1/4"	8
METAL SUPPORT	4

PRODUCT IMAGE SHOWN IS FOR ILLUSTRATIVE PURPOSES ONLY, SHOULD NOT BE TAKEN AS REFERENCE POINT



## ASSEMBLY INSTRUCTIONS

I-MIX-C010-BK