

X A HOWARD MILLER COMPANY

79188 TABLE DESK

A	В	C	D	E	
ALLEN BOLT 5/16" X 2" (10 PCS.)	FLAT WASHER M8 (10 PCS.)	SPRING WASHER M8 (10 PCS.)	SCREW Ø8 X 1 ½" (2 PCS.)	ALLEN KEY L5 (FOR ALLEN BOLT) 1 PC.	
	0	0	411111111 11		

PART INSIDE						
1 TOP ASSEMBLY (1 Pc)	2 LEGS (2 Pcs)	3 Stretcher (1 Pc)				

Assembly Instruction

STEP 1.

LAY TOP ASSEMBLY OF THE TABLE DESK UPSIDE DOWN ON A SOFT. CLEAN AND FLAT SURFACE. PULL OUT DRAWERS ON SOFT MATERIAL TO PREVENT SCRATCHING SURFACE.

ALIGN LEG (2) TO HOLES IN THE TOP ASSEMBLY (1) AND CONNECT USING FLAT WASHER (B), SPRING WASHER (C), ALLEN BOLT (A) AND ALLEN KEY (F) PROVIDED. DO NOT FULLY TIGHTEN THE BOLTS

