

## Contents:

## Tools required: 9/16" socket or wrench

- A. 2 Pedestal ends B. 1 – Stretcher - 24" (42" for Model #3002 & 3602)
- C. 1 Table top
- D. 4 4" Lag bolts
- E.  $4 2\frac{1}{2}$ " Lag bolts
- F. 8 Washers

## Please read instructions completely prior to starting.

- 1. Fasten pedestal ends "A" to the stretcher "B" using four 4" lag bolts "D" with 4 washers "F". Leave these bolts loose until this assembly has been fastened to the table top.
- 2. Fasten the 2 pedestals "A" to the table top "C" using four 2 ½" lag bolts "E" with 4 washers "F". The pre-drilled bolt holes "G" on the pedestals should line up with the pilot holes "H" on the table top.
- 3. Tighten all lag bolts until the washers are snug against the wood.

