Installation Instructions

Before you begin - Read these instructions completely and carefully.

Note to Installer: Be sure to leave these instructions with the Consumer.

Fip Over Hazard.

These appliances are top heavy, especially with any doors open, and must be secured to prevent tipping forward which could result in death or serious injury. Read and follow the entire installation instructions for securing the appliance with the anti-tip system before installing door panel kit.

Stainless Steel Door Panel Kit

Note to Consumer: Keep these instructions with your Installation Instructions for future reference.



Hazard

Door Trim Pinch Point

Improper installation can lead to a finger pinch point hazard between the side door trim and the cabinets when operating the door, especially with children. To minimize this risk you must follow the installation instructions for cabinet dimensions, trim assembly, and door stop angle.

This kit provides for the installation of the Stainless Steel Door Panel Assemblies

ZK1SN189NLH	LH 18" STAINLESS STEEL DOOR PANEL
ZK1SN184NRH	RH 18" STAINLESS STEEL DOOR PANEL
ZK1SN249NLH	LH 24" STAINLESS STEEL DOOR PANEL
ZK1SN244NRH	RH 24" STAINLESS STEEL DOOR PANEL
ZK1SN309NLH	LH 30" STAINLESS STEEL DOOR PANEL
ZK1SN304NRH	RH 30" STAINLESS STEEL DOOR PANEL
ZKSP1H1CNSS	MINIMALIST HANDLE FOR STAINLESS STEEL PANELS ONLY
ZKSP1H1PNSS	STATEMENT HANDLE FOR STAINLESS STEEL PANELS ONLY

Tools and Materials Required:

T20 and T30 Torx driver / bits

Instructions for this kit are also included in the full installation instructions included with the unit.

INSTALL STAINLESS PANEL

 Remove bottom hinge cover and retain the 4 T30 Torx screws for later installation.



Open door to 90°. Slide the panel onto the door with the panel brackets interlocking on top and bottom with the door brackets (make sure not to slide the panel into the cabinetry surround). Center the panel on the door, then slowly close the door while watching to make sure the panel does not contact the surrounding cabinetry.



■ With the door fully closed, carefully slide the panel towards the cabinetry with the goal gap of 1/8".



FOLLOW THE REMAINDER OF THE STAINLESS DOOR PANEL INSTALLATION INSTRUCTIONS IN THE UNIT INSTALLATION INSTRUCTIONS TO ADJUST AND SECURE THE DOOR PANEL.