



## PROVIDENCE DAYBED

Model # 380-01

Model # 380-02

Customer Service  
Phone Number:  
502 562-0000  
01-19-05

Examine all packaging material for small parts that may have come loose during shipment. Periodic checks are recommended to insure that all components are in proper position, tight and free from damage. Keep this assembly instruction for future reference. Adult assembly required. Online Parts Request Form: [www.hillsdalehouse.com/parts\\_request.html](http://www.hillsdalehouse.com/parts_request.html)

<p><b>HARDWARE LIST</b></p> <p>A (8) Short Allen Bolts B (4) Long Allen Bolts C (8) Metal Washers D (4) Foot Glides E (4) Foot Casting F (4) Finials G (1) Allen Wrench</p>	<p><b>PARTS LIST</b></p> <p>H (1) Right Side Frame I (1) Left Side Frame J (1) Back panel</p>	
---	---	--

  

**FIGURE 1**

**FIGURE 2**

**STEP 1**

Attach Back Panel (J) to both Right Side Frame (H) and Left Side Frame (I) using 2 Long Allen Bolts (B) per each side . Tighten All Bolts . See Figure 1 .

**STEP 2**

Attaching 1 Foot Casting (E) and 1 Foot Glide (D) to bottom of each casting . Attach each Finial (F) to top of each post on Right Side Frame (H) and Left Side Frame (I) by screwing into place .

**STEP 3**

Attach Bed Frame ( \*Not Included ) to posts on both Right Side Frame (H) and Left Side Frame (I) using 2 Short Allen Bolts (A) & 2 Metal Washers (C) per each post . Tighten All Bolts . See Figure 2 . Assembly is now complete .

**Bed Frame  
\* Not Included  
as shown in  
Figure 2.**

**CARE & MAINTENANCE:** The touch of a soft cloth is all the maintenance the finish will ever need. Please do not use harsh or abrasive cleaners for polishing, as they may cause damage to the finish. Periodic checks are recommended to make sure that all bolts, screws and nuts are securely tightened.

		BRASSOM FURNITURE	
		CUST	HSD
ITEM NO.	918 DB	SIZE	
NAME			
DATE	2005/01/19		