



INSTALLATION INSTRUCTIONS

- 1. **Tape this template to the drywall**
Center the template between two studs. Make sure that it's 14" W x 8" H
- 2. **Mark the Location of the holes.**
Use a punch or screw to mark holes in each corner.
- 3. **Remove the template and drill the holes**
Use an 1/8" or smaller bit, drill through all the holes marked in previous step.
- 4. **Cut the drywall opening**
Use a drywall saw to cut between the holes drilled.

THIS MUST BE PRINTED ON AN A3 PAGE (17" W X 11" H) SHEET OF PAPER AT A 1:1 RATIO!

Please be sure to check printer settings so no re-sizing occurs.