









Assembly Instruction for  
BAR SLAT BACK STOOL W/WOOD SEAT  
DFN100BSBSBTWE


- Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.
1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
  2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
  3. Please do not over tighten screws or bolts.
  4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PART LIST FOR COUNTER SIDE CHAIR			
No.	PART DESC	CODE.	Q'TY
A	BAR SLAT BACK STOOL - BACK FRAME	PDFN100BSBSBFR	1
B	BAR SLAT BACK STOOL - WOOD SEAT W/ FRAME	PDFN100BSBSSEA	1
C	BAR SLAT BACK STOOL - L&R FRONT LEG	PDFN100BSBSLEG	2
D	BAR SLAT BACK STOOL - SIDE STRETCHER LEFT / RIGHT	PDFN100BSBSSTR1	2
E	BAR SLAT BACK STOOL - FRONT STRETCHER	PDFN100BSBSSTR2	1


HARDWARE LIST PACKED INSIDE BOX			
No.	HARDWARE DESC	CODE.	Q'TY
1	 ALLEN BOLT (Ø1/4**1-5/8")	PDFN100BSBSHW	2
2	 ALLEN BOLT (Ø1/4**2-3/8")		4
3	 ALLEN BOLT (Ø1/4**3")		4
4	 SPRING WASHER (Ø1/4")		10
5	 FLAT WASHER (Ø1/4")		10
6	 SCREWS (#4*1-1/2")		6
7	 ALLEN KEY (Ø1/8")		1

 Only tighten all bolts when all bolts aligned with bolt inserts.

STEP:1



STEP:2



COMPLETED

