


Assembly Instructions

ITEM NO. D2210-20
LUMINA - DINING CHAIR
(2 PER CARTON)

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items and compare with the parts list and/or hardware list shown below.

Caution : please read the instruction thoroughly before assembly.


1. We recommended that you assemble this product with the assistance of another person, this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
2. Please do not tighten screws or bolt until the assembly is completed.
3. Please put all parts on a non-abrasive floor before assembly and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PARTS LIST			
NO.	DESCRIPTION	SKETCH	QTY
A	CHAIR BACK		2 pc
B	SEAT		2 pcs
C	FRONT LEG		4 pc

HARDWARE LIST			
NO.	DESCRIPTION	SKETCH	QTY
1	SMALL BOLT - M6 x 3/8"		4 pcs
2	MEDIUM BOLT - M6 x 2-3/8"		8 pcs
3	LARGE BOLT - M6 x 3-5/32"		8 pcs
4	SPRING WASHER M6		20 pcs
5	FLAT WASHER - M6 x 3/4"		20 pcs
6	WOOD DOWEL - M8 x 1-3/16"		2 pcs
7	ALLEN KEY - M4		1 pc

WEIGHT CAPACITY (PER CHAIR)	300 lbs
-----------------------------	---------


STEP 1 : Install the Wood Dowel (6) to Seat (B).




Assembly Instructions

ITEM NO. D2210-20
LUMINA - DINING CHAIR
(2 PER CARTON)

STEP 2 : Assemble the Chair Back (A) to Seat (B) by using Allen Key (7) with hardware 1, 4, and 5.
*DO NOT TIGHTEN THE BOLTS




STEP 3 : Assemble the Chair Back (A) to Seat (B) by using Allen Key (7) with hardware 3, 4, and 5.
*DO NOT TIGHTEN THE BOLTS



Assembly Instructions

ITEM NO. D2210-20
LUMINA - DINING CHAIR
(2 PER CARTON)

STEP 4 : Assemble the Front Leg (C) to Seat (B) by using Allen Key (7) with hardware 2,4, and 5.
*DO NOT TIGHTEN THE BOLTS



STEP 5 : To level the chair, stand the chair up on a flat surface and tighten all the bolts by using Allen Key (7).

