



CB300UI

en	Instruction Manual
it	Manuale di istruzioni
fr	Notice d'Utilisation
es	Manual de instrucciones



Please read this user manual first!

Dear Customer,

We hope that your product, which has been produced in modern plants and checked under the most meticulous quality control procedures, will provide you an effective service.

Therefore, read this entire user manual carefully before using the product and keep it as a reference. If you handover the product to someone else, give the user manual as well.

The user manual will help you use the product in a fast and safe way.

- Read the manual before installing and operating the product.
- Make sure you read the safety instructions.
- Keep the manual in an easily accessible place as you may need it later.
- Read the other documents given with the product.

Remember that this user manual is also applicable for several other models. Differences between models will be identified in the manual.

Explanation of symbols

Throughout this user manual the following symbols are used:

 Important information or useful tips.

 Warning against dangerous conditions for life and property.

 Warning against electric voltage.

VISIT OUR WEBSITE TO:




Get usage advice, brochures, trouble shooter, service and repair information:
www.smeg.com/services/customer-service

Subject to change without notice.

CONTENTS

1 Your refrigerator	4	4 Preparation	14
2 Important Safety Warnings	5	Reversing the doors	15
Intended use	5	5 Using your refrigerator	18
For products with a water dispenser; ..	7	Freezing fresh food	20
Child safety	8	Recommendations for preservation of frozen food	21
Compliance with WEEE Directive and Disposing of the Waste Product:	8	Placing the food	21
Compliance with RoHS Directive:	8	Deep-freeze information	21
Package information	8	Ice Machine	22
HC Warning	9	6 Maintenance and cleaning	23
Things to be done for energy saving ..	9	7 Troubleshooting	24
3 Installation	11		
Points to be paid attention to when the relocation of the refrigerator	11		
Electrical connection	11		
Door Open Warning	12		
Disposing of the packaging	12		
Disposing of your old refrigerator	12		
Placing and Installation	12		
Changing the illumination lamp	13		
Connecting the water hose to the refrigerator	13		
Connecting the water line to the water supply	13		

1 Your refrigerator



- 1.** Butter & Cheese sections
- 2.** Adjustable door shelves
- 3.** Bottle holder
- 4.** Bottle shelf
- 5.** Adjustable front feet
- 6.** Freezer compartment
- 7.** Flap

- 8.** Icebox / Ice-making compartment
- 9.** Crisper
- 10.** Crisper cover and glass
- 11.** Adjustable shelves
- 12.** Fan
- 13.** Indicator panel

i Figures that take place in this instruction manual are schematic and may not correspond exactly with your product. If the subject parts are not included in the product you have purchased, then it is valid for other models.

2 Important Safety Warnings

Please review the following information. Failure to observe this information may cause injuries or material damage. Otherwise, all warranty and reliability commitments will become invalid.

The usage life of the unit you purchased is 10 years. This is the period for keeping the spare parts required for the unit to operate as described.

Intended use

This product is intended to be used

- indoors and in closed areas such as homes;
- in closed working environments such as stores and offices;
- in closed accommodation areas such as farm houses, hotels, pensions.
- This product should not be used outdoors.

General safety

- When you want to dispose/scrap the product, we recommend you to consult the authorized service in order to learn the required information and authorized bodies.
- Consult your authorized service for all your questions and problems related to the refrigerator. Do not intervene or let someone intervene to the refrigerator without notifying the authorised services.

- For products with a freezer compartment; Do not eat cone ice cream and ice cubes immediately after you take them out of the freezer compartment! (This may cause frostbite in your mouth.)
- For products with a freezer compartment; Do not put bottled and canned liquid beverages in the freezer compartment. Otherwise, these may burst.
- Do not touch frozen food by hand; they may stick to your hand.
- Unplug your refrigerator before cleaning or defrosting.
- Vapor and vaporized cleaning materials should never be used in cleaning and defrosting processes of your refrigerator. In such cases, the vapor may get in contact with the electrical parts and cause short circuit or electric shock.
- Never use the parts on your refrigerator such as the door as a means of support or step.
- Do not use electrical devices inside the refrigerator.
- Do not damage the parts, where the refrigerant is circulating, with drilling or cutting tools. The refrigerant that might blow out when the gas channels of the evaporator, pipe extensions or surface coatings are punctured causes skin irritations and eye injuries.

