

ASSEMBLY INSTRUCTION

DESCRIPTION: ENTERTAINMENT CONSOLE

ITEM#:406W-TV66


Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts List Below:




HOW TO REMOVE DRAWER simultan one side

To remove drawer, simultaneously pull tab up on one side and push down on the other and remove drawer.

PARTS LIST:



HARDWARE LIST			
NO.	Drawing	Description	Q'ty
Α		Furniture Tipping Restraint	1 Set



CLEANING INSTRUCTION

Clean the Console surface with a furniture polish and a soft cloth.

Made inVietNam