







Product Assembly Instructions LCLEBDCHKGBX1 / LCLEBDCHKGBX2


PART LIST

 A : HEADBOARD x1	 B : FOOTBOARD x1	 C : SIDE RAIL (L & R) x2
 D : SLAT x14	 E : CENTER SLAT x1	 F : CENTER SLAT SUPPORT x3


HARDWARE LIST

 G : JCBB SCREW M8 x 16MM x8	 H : ALLEN KEY M5 (SHORT) x1	 I : JCBC SCREW M6 x 20MM (BLK) x8
 J : SPRING WASHER 1/4" (BLK) x8	 K : FLAT WASHER 1/4" (BLK) x8	 L : JCBC SCREW M6 x 50MM x3
 M : SPRING WASHER 1/4" x3	 N : PAN HEAD SCREW M4 x 25MM x28	 O : ADJUSTABLE SCREW x3
 P : ALLEN KEY M4 (BALL SHAPE) x1		


STEP 1



STEP 2



STEP 3







Product Assembly Instructions

LCLELABL

PART LIST



A : NIGHT STAND x1



B : METAL LEG x4

HARDWARE LIST



C : JCBC SCREW M6 x 20MM(BLK) x8



D : SPRING WASHER 1/4"(BLK) x8




E : FLAT WASHER 1/4"(BLK) x8




F : ALLEN KEY M4 (BALL SHAPE) x1


STEP 1



STEP 2



STEP 3




ASSEMBLY COMPLETED




Product Assembly Instructions

LCLEDRBL


PART LIST



A : DRESSER x1



B : METAL LEG x4



C : METAL CENTER LEG x1

HARDWARE LIST



D : JCBC SCREW M6 x 20MM(BLK) x10



E : SPRING WASHER 1/4"(BLK) x10



F : FLAT WASHER 1/4"(BLK) x10



G : ALLEN KEY M4 (BALL SHAPE) x1



H : WALL SCREW M4 x 18MM x1



I : WALL SCREW M4 x 50MM x1




J : L-BRACKET x2




K : BELT x1


STEP 1




STEP 2




STEP 3



STEP 4



STEP 5



ASSEMBLY COMPLETED