


B E R N H A R D T


LIVING

NEST PLUSH SECTIONAL



P3330 ARMLESS CHAIR

W 36 | D 38.50 | H 33 in.
SH 17 | SD 24 in.




P3332 CORNER CHAIR

W 38.50 | D 38.50 | H 33 in.
SH 17 | SD 24 in.




P3300 COCKTAIL OTTOMAN

W 54 | D 30 | H 17 in.




P3338 LEFT ARM CHAISE

W 45 | D 68.50 | H 33 in.
SH 17 | AH 22 | SD 54 in.




P3337 RIGHT ARM CHAISE

W 45 | D 68.50 | H 33 in.
SH 17 | AH 22 | SD 54 in.



P3342 LEFT ARM LOVESEAT

W 80.50 | D 38.50 | H 33 in.
SH 17 | AH 22 | SD 24 in.



P3341 RIGHT ARM LOVESEAT

W 80.50 | D 38.50 | H 33 in.
SH 17 | AH 22 | SD 24 in.