



## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



*Fine Furniture for every stage of life*

508963  
**ACCENT CHAIR**

REVISION 0 : 09/08/2025

ITEM: 508963

## ASSEMBLY INSTRUCTIONS




### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING !

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

5 MINUTES

## PARTS IDENTIFICATION

A. CHAIR



1PC

B. LEG



4PCS

C. PATTERNED PILLOW




1PC


ITEM: 508963  
ASSEMBLY INSTRUCTIONS

**COASTER**  
FINE FURNITURE


STEP 1



STEP 2



ITEM: 508963  
ASSEMBLY INSTRUCTIONS



Note: Dimension tolerance  $\pm 5\%$

