




ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

651354
Motion Sofa

ITEM: **651354**

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME


5 MINUTES

PARTS IDENTIFICATION

A LEFT BACK 1PC




B MIDDLE BACK 1PC



C RIGHT BACK 1PC



D BASE 1PC



E LEFT EAR 1PC



F RIGHT EAR 1PC




ITEM: **651354**


ASSEMBLY INSTRUCTIONS




STEP 1




STEP 2





STEP 3



STEP 4 **COMPLETE**



ITEM: **651354**



Note: Dimension tolerance $\pm 5\%$