

ASSEMBLY INSTRUCTIONS


MODEL #

CM4193-C


Questions?

GIVE US A CALL: 1-888-980-5122
MON-FRI 8:30AM - 5:30PM (PT)

TOOLS REQUIRED



Allen Wrench
(Included)



2 - People
Recommended

ASSEMBLY RATING



EASY → DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



FOA Intro

Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific Time and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.

 **Consumer Hotline**
Toll-Free 1-888-980-5122

 **Monday to Friday**
8:30AM- 5:30PM (PT)

 **WEBSITE**
www.foagroup.com

 **E-MAIL**
cs.ec@foagroup.com

    foagroup

 FurnitureOfAmerica

CHECK BEFORE STARTING

Are you missing anything?
Double-check all parts, hardware and accessories listed are all accounted for.


Check out our Quick Tips!
We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

Should we send any replacements?
Are there any irregularities or flaws in the parts? We can send replacements!

Prep Time!
Please review the assembly instructions and all diagrams prior to assembling.



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.




Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.




Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.


IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

COFFEE TABLE

CM4193-C




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS

#1 1pc




TOP BOX

#2 1pc




SHELF

#3 2pcs




LEG 1

#4 2pcs




LEG 2

#5 2pcs




TOP CROSSBAR

#6 2pcs




TOP SUPPORT CROSSBAR

#7 2pcs



BOTTOM CROSSBAR



#8 1pc



BOTTOM SUPPORT CROSSBAR

COFFEE TABLE

CM4193-C



HARDWARE

#A 28pcs



Short Bolt 1/4" x 12mm

#B 4pcs



Medium Bolt 1/4" x 22mm

#C 2pcs



Long Bolt 1/4" x 47mm

#D 2pcs




Screw 4 x 25mm

#E 4pcs



Washer 16mm

#F 4pcs



Felt Pad

#G 1pc





Allen Wrench 4mm

ASSEMBLY INSTRUCTIONS

1

- Part #3 x2pcs Hardware #A x20pcs
- Part #4 x2pcs Hardware #E x4pcs
- Part #5 x2pcs Hardware #F x4pcs
- Part #6 x2pcs
- Part #7 x2pcs


- I. Align the Top Crossbar (#5) to the Leg 1 (#3) and Leg 2 (#4). Secure using Short Bolt (#A).
- II. Align the Top Support Bar (#6) to the Leg1 (#3) and Leg 2 (#4). Secure using Short Bolts(#A).
- III. Align the Bottom Crossbar (#7) to the Leg1 (#3) and Leg 2 (#4). Secure using Short Bolt (#A) with Washer (#E).
- IV. Add Felt pads (#F) to Leg 1 (#3) and Leg 2 (#4).



2

- Part #1 x1pc
- Hardware #A x8pcs

- Align both legs to the Top Box (#1) and secure with Short Bolt (#A).




ASSEMBLY INSTRUCTIONS

3

Part #8 x1pc
Hardware #C x2pcs


Attach the Bottom Support Crossbar and secure using Long Bolt (#C).



4


Part #2 x1pc
Hardware #B x4pcs
Hardware #D x2pcs

Align the Shelf (#2) to the legs and the Bottom Support Crossbar (#8). Secure to support bar using Screw (#D). Secure to the legs using Medium Bolt (#B).



ASSEMBLY INSTRUCTIONS

5



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.