










ASSEMBLY INSTRUCTION


ITEM: 6952-75217B-80 Rectangle Dining Table Base
6952-75217T-80 Rectangle Dining Table Top

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.


HARDWARE PACK				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Allen Wrench	108*76*5MM	1 PC
B		Bolt	5/16*100mm	4 PCS
C		Bolt	5/16*50mm	12 PCS
D		Lock Washer	5/6"	16 PCS
E		Flat Washer	5/16*22mm	16 PCS

PART LIST			
NO.	DRAWING	DESCRIPTION	Q'TY
①		Table Top	1 PC
②		Base	2 PCS
③		Stretchers	2 PCS
④		Leaf	2 PCS



STEP 1:
Insert bolts (B) to base (2)
and tighten to table top(1)
by allen wrench (A).

STEP 2:
Insert bolts (C) to base (2)
and tighten to table top(1)
by allen wrench (A).




ASSEMBLY INSTRUCTION

ITEM: 6952-75217B-80 Rectangle Dining Table Base
6952-75217T-80 Rectangle Dining Table Top


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.



STEP 3:


Attach stretcher (3) to table top (1).



ITEM: 6952-75217B-80 Rectangle Dining Table Base
6952-75217T-80 Rectangle Dining Table Top


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.



STEP 4:

Pull out both ends of table top (1) as the arrow direction, place the leaf (4) between and push them together, lock the latches.



Note: Take opposite actions to remove table leaf.