

## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



### 551511 ARMLESS CHAIR

REVISION 0 : 05/17/2019 REVISION 1 : 01 /09/2020

REVISION 2: 03/13/2020


PAGE 1 OF 4

**COASTERFURNITURE.COM** 

### ITEM: 551511


#### **ASSEMBLY INSTRUCTIONS**






# ITEM: **551511**ASSEMBLY INSTRUCTIONS







Note: Dimension tolerance ±5%



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



### 551512 CORNER

REVISION 0: 05/17/2019

REVISION 1:01/09/2020 REVISION 2:03/13/2020 PAGE 1 OF 4

**COASTERFURNITURE.COM** 

### ITEM: 551512


#### **ASSEMBLY INSTRUCTIONS**



## Assembly Instruction ASSEMBLY TIPS: 1. Remove hardware from box and sort by size. 2. Please check to see that all hardware and parts are present prior to start of assembly. 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly. Warning! Do not attempt to repair or modify parts that are broken or defective. Please contact the store immediately. This product is for home use only and intended for commercial establishment. **PARTS IDENTIFICATION** 1PC CORNER A B 4PCS LEG PILLOW 2PCS

# ITEM: **551512**ASSEMBLY INSTRUCTIONS







Note: Dimension tolerance ±5%