

PARTS LIST / LISTE DES PIÈCES / LISTA DE PIEZAS

ITEM NO. / ARTICLE NO. / ARTICULO NO : P377134

Description / La Description / Descripción : Desk vanity/ Vanité de bureau/ Tocador de escritorio





WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!



 A x1 Top Table x1 Table supérieure x1 Mesa superior	 B * x8 Upper Leg x8 Patte supérieure x8 Pata superior	 C * x8 Lower Leg x8 Patte inférieure x8 Pata inferior	 D * x1 Metal Frame x1 Cadre en métal x1 Armazón de metal
 1 * x16 Bolt Ø5/16"xL50mm x16 Vis à tête creuse hexagonale Ø5/16"xL50mm x16 Perno Allen Ø5/16"xL50mm	 2 * x16 Lock washer Ø5/16xØ14x1mm x16 Rondelle de blocage Ø5/16xØ14x1mm x16 Arandela de Seguridad Ø5/16xØ14x1mm	 3 * x16 Flat Washer Ø5/16xØ18x1mm x16 Rondelle plate Ø5/16xØ18x1mm x16 Arandela plana Ø5/16xØ18x1mm	 4 * x1 Allen Key 5mm x1 Clé hexagonale 5mm x1 Llave Allen 5mm
 5 x1 Furniture Tipping Restraint x1 Systeme antibasculement x1 Control para evitar vulcos	* Replaceable Part		



⚠ WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!

Note: When assembly the legs to the tabletop, you need to loosen the screws first, then put the iron frame in before tightening




WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:


- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!

Note: When assembly the legs to the tabletop, you need to loosen the screws first, then put the iron frame in before tightening



STEP 3
ÉTAPE 3
PASO 3



STEP 4
ÉTAPE 4
PASO 4


⚠ WARNING



Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.


*This is a permanent label.
Do not remove!*



- x1 RP377134-KNOB- Knob with Screw
- Poignée et vis
- Tirador y Tornillo



- 1 Set COMGLIDE-10-45 -Common Glide
- Glissière
- Carril de deslizamiento




- x1 RP377134-FRAME- Metal Frame
- Cadre en métal
- Armazón de metal



- x8 RP377134-LEGU- Upper Vanity Leg
- Patte supérieure
- Pata superior



- x8 RP377134-LEGL - Lower Vanity Leg
- Patte inférieure
- Pata inferior



- x1 RP377-134-HWKIT- Hardware kit list
- Liste des pièces de quincaillerie
- Lista del kit de materiales



- x1 RC-ANTI-TIP-M - Metal Anti- tip kit
- Systeme antibasculement
- Control para evitar vulcos



- x8 RC-FG-WHITE - White Leveler
- Patin réglable
- Nivelador

Protect Your Wood or Laminate Flooring

*This statement applies to any floor without carpet.

If not careful, all furniture including upholstery and case pieces can scratch, scuff and even gouge floors. The recommendation is to have felt, rubber pads or area rugs under furniture on flooring without carpet.

Moving your furniture

Pushing and dragging furniture over floors without carpet can lead to scratches and scuffs. Have someone

help when moving the larger pieces of furniture by lifting, try using a dolly or moving pads.

Felt and rubber pads

Applying furniture pads to the feet of furniture helps cushion contact points. Furniture pads can be found at local hardware stores. Felt pads slide easily across the floor, making them ideal for dining chairs and other pieces that move with use. Rubber pads will help furniture stay in place and are perfect for larger pieces, like sofas and loveseats.

Area rugs and rug pads

Using an area rug under furniture is another way to protect your floor from scratches and scuff marks. A rug pad under the area rug will provide extra cushion and added protection.