

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



193811 DINING TABLE

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- Please check to see that all hardware and parts are present prior to start of assembly.
 Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.


 2. This product is for home use only and not intended for commercial establishments.




HARDWARE IDENTIFICATION							
Z	HARDWARE NAME	FIGURE	QTY				
1	BOLT	M8*20	6PCS				
2	BOLT	M8*25	6PCS				
3	BOLT	M8*50	6PCS				
4	WASHER		6PCS				
5	SPRING WASHER		6PCS				
6	ALLEN WRENCH	M_{5}	1PC				
7	RUBBER PAD	<->80*80	3PCS				

ASSEMBLY INSTRUCTIONS









ASSEMBLY INSTRUCTIONS








ASSEMBLY INSTRUCTIONS







ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



193812 DINING CHAIR

ASSEMBLY INSTRUCTIONS



- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

 2. This product is for home use only and not intended for commercial establishments.







PARTS IDENTIFICATION

	PART NAME	FIGURE	QTY
A	SEAT AND BACK		1PC
В	BASE		1PC

HARDWARE IDENTIFICATION


Z	HARDWARENAME		FIGURE	QTY
1	BOLT	6*18mm		4PCS
2	ALLEN WRENCH φ18mm			4PCS
3	WASHER	5mm		1PC

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ASSEMBLY INSTRUCTIONS














COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS





COASTERFURNITURE.COM