


POLY ADIRONDACK ROCKING CHAIR


EASY ASSEMBLY INSTRUCTIONS



Step 1 (Open legs and attach arms)



Lay the chair flat and open the front legs. Align the hole on the front side of the arm with the front leg. Insert a short bolt into the washer, arm and front leg. Slide on another washer and tighten a nut onto the bolt.




Lift the back up and insert a long bolt into the washer, back of the arm and back. Slide on another washer and tighten a nut onto the bolt.

(With the legs out and seat back already up, repeat steps 1 & 2 for opposite side)

ROCKING CHAIR CONT.

Step 3 (Attach runners)



Place the front of the runner on the inside of the front leg. Insert a long bolt into the washer, front leg and runner. Slide on another washer and tighten a nut onto the bolt.



Place the back of the runner on the outside of the back legs. Insert a long bolt into the washer, front leg and runner. Slide on another washer and tighten nut onto bolt.

(Repeat this process for the opposite side)

ROCKING CHAIR CONT.



Step 4 ENJOY!

Customer Service: Call 1-866-872-3437. Ask for Darren.