






ITEM NAME/NOM D'ITEM: IZOLA DINING TABLE

ITEM # /NO. ITEM: 109856


PARTS LIST/LISTE DES PIÈCES

(1)	(2)	(3)
		A.  25x8mm x3 B.  25x10mm x3 C.  20x13mm x3 D.  5mm x1
x1	x1	


ASSEMBLY INSTRUCTIONS/INSTRUCTIONS D'ASSEMBLAGE

I


Remove the bolt (A), washers (B & C) from Dining top with the help of allen key (D)



II



III



IV

