

C091-020-441 CONSOLE TABLE

LILLIAN

ASSEMBLY INSTRUCTIONS

PLEASE UNPACK ALL PARTS AND CHECK AGAINST PARTS LIST ON THIS INSTRUCTION SHEET BEFORE DISCARDING PACKING AND CARTON!!

1) Turn the Top face down on a soft, clean surface.

2) Attach the Front Leg & Back leg to top using lock washer (A), flat washer (B) and Bolt (C) tighten with wrench provided (D) as shown in Drawing A


3) Tighten the entire bolts then return the table to upright position

Note: Touch-up pen is provided for repair of minor issues resulting from transit, handling and normal use.

*** NOTE KEEP THIS SHEET!!! ***

In the unlikely event that you would need a replacement part for your furniture, please contact your local authorized Caracole International dealer. If you need replacement hardware quickly, it could be purchased from your local hardware store.

C091-020-441 CONSOLE TABLE		
Part Description	Part No.	QTY
Soft-closing Guide	C091-020-441-20424	1set
Anti-tip Restraint	C093-020-011-30157	1
Back Leg	C091-020-441-2020	2
Front Leg	C091-020-441-2019	2
Drawer Pull	C093-020-011-3081	1
Touch-up Pen	C093-020-011-30439	1
Adjustable Floor Glide	C093-020-011-3075	4
RTA Hardware	C093-020-011-3001	1



NO.	Hardware List			Q'ty
A		Lock Washer	5/16"	24
B		Flat Washer	5/16"	24
C		Bolt	5/16"	24
D		Wrench	1	1

