


# ZEPHYR

MWD2401AS



# ZEPHYR

## MWD2401AS

Ref #	Part #	Description	Qty.
1	50230043	Door Assembly	1
1-4	50320065	Door Slider	3
2	11000177	Display Panel Assembly	1
3	50120232	Outer Case Side Panel, Left	1
4	54190085	Mounting Plate	2
5	54140378	Guide Plate Bracket	1
6	54110135	Wind Guide Cover	1
7	54110136	Wind Guide	1
8	11040035	Micro Switch Assembly, Left	1
9	54140379	Air Damper Bracket	1
10	54110137	Wind Guide Cover	1
11	54140369	Hinge Support Bracket	1
12	50130186	Bottom Panel, Door	1
13	54190083	Base Plate	1
14	54140371	Filter Bracket	1
15	11010183	Control Board, Noise Filter	1
16	12170009	Fuse	1
17	11040034	Micro Switch Assembly, Right	1
18	54110138	Wind Guide Cover	1
19	54140370	Capacitor Bracket	1
20	11050034	Diode	1
21	12050041	Capacitor	1
22	50500182	Door Slider Motor Assembly	1
23	12110024	Transformer	1
24	50120231	Outer Case Side Panel, Right	1
25	11030200	Main Wire Harness	1
26	50120233	Outer Case Top Panel	1
27	12010024	Incandescent Bulb	1

28	12120101	Synchronous Motor	1
29	54140377	Lamp Bracket	1
30	12130049	Stirrer Fan Assembly	1
31	54140376	Control Board Bracket	1
32	11010185	Control Board	1
33	12020001	Magnatron	1
34	11010184	Control Board	1
35	12130048	Fan Assembly	1
36	54140368	Fixing Bracket, Left	1
37	11050036	Humidity Sensor	1
38	54150027	Spring	2
39	50120244	Outer Case, Back Panel	1
40	11030199	Power Cord	1
41	54140367	Fixing Bracket, Right	1
42	54110139	Wind Guide Cover	1
43	11050035	Thermostat	2
50	01020086	Screw, ST3.9*8	9
51	01020096	Screw, ST3*8	5
52	00100031	Nut, M4*4.5	5
53	01020089	Screw, CT4*8	35
54	01020085	Screw, ST3.9*12	13
55	01020095	Screw, M4*16	4

MAR24.0201



# ZEPHYR

## MWD3001AS

Ref #	Part #	Description	Qty.
1	50230045	Door Assembly	1
2	11000186	Display Panel Assembly	1
3	54190088	Mounting Plate	2
4	50120253	Outer Case Left Panel	1
5	54140378	Guide Plate Bracket	1
6	54110135	Wind Guide Cover	1
7	54110136	Wind Guide Cover	1
8	54140379	Air Damper Bracket	1
9	54110137	Wind Guide Cover	1
10	54140369	Hinge Support Bracket	1
11	54110142	Wave Guide Cover	1
12	11050035	Thermostat	1
13	11040035	Micro Switch Assembly, Left	1
14	50130186	Door Bottom Panel	1
15	54190083	Base Plate	1
16	54140371	Noise Filter Bracket	1
17	11010183	Noise Filter Control Board	1
18	12170009	Fuse	1
19	54110138	Wind Guide Cover	1
20	54140370	Capacitor Holder	1
21	11050034	Diode	1
22	12050041	Capacitor	1
23	50500182	Door Slider Motor Assembly	1
24	12110024	Transformer	1
25	50120251	Outer Case Right Panel	1
26	11030200	Main Wire Harness	1
27	11040034	Micro Switch Assembly, Right	1
28	50120254	Outer Case Top Panel	1

29	12010024	Incandescent Light Bulb	1
30	12120101	Synchronous Motor	1
31	54140377	Lamp Bracket	1
32	12130049	Stirrir Fan Assembly	1
33	11050035	Thermostat	1
34	54140376	Control Board Bracket	1
35	11010185	Main Control Board	1
36	12020001	Magnatron	1
37	11010184	Power Supply Control Board	1
38	12130048	Fan Assembly	1
39	54140368	Fixing Bracket Left	1
40	54150027	Spring	2
41	50120252	Outer Case Back Panel	1
42	11050036	Humidity Sensor	1
43		Power Cord	1
44	54150029	Cable Clip	2
45	54140367	Fixing Bracket Right	1
46	54110139	Wind Guide Cover	1
50	01020095	Screw, M4*16	4
51	01020085	Screw, ST3.9*12	13
52	01020096	Screw, ST3*8	5
53	01020089	Screw, CT4*8	35

JUL24.0101