














Warning :

- Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.
- To prevent possible scratches and damage, this furniture **MUST BE ASSEMBLED BY TWO PEOPLE** on a soft surface such as a blanket or carpet.



Components and Hardware List

Top Assembly  (A) 1 pc.	Leg Assembly (Left)  (B) 1 pc.	Leg Assembly (Right)  (C) 1 pc.	Stretcher  (D) 1 pc.	Allen Head Bolt 5/16" x 1 1/2 "  (E) 12 pcs.
Spring Washer 5/16"  (F) 12 pcs.	Flat Washer 5/16" x 3/4"  (G) 12 pcs.	Allen Head Bolt 1/4"x 5/8"  (H) 8 pcs.	Spring Washer 1/4"  (I) 8 pcs.	Flat Washer 1/4" x 1/2"  (J) 8 pcs.
			L - Bracket  (K) 4 pcs.	4 mm Allen Key  (L) 1 pc.




#38430
Writing Desk


Step 1 : Remove Drawer




Step 2 : Do not fully tighten the bolts




Step 3 : Using the Allen key to tighten all bolts



Step 4 : Attach Drawer



Step 5 :



For product and personal safety, a Furniture Tipping Restraint kit has been included with this unit which can help to minimize the risk of the unit accidentally tipping forward, if used and properly installed per the manufacturer's instructions.