




1327-50PH in Leather 749-11

FLEXSTEEL®



1327-50PH in Leather 749-11




1327-50PH in Leather 749-11

- 50PH
- FEATURES
- Flexsteel Spring Unit
- DualFlex
- Back Construction
- Attached
- Seat Construction
- Attached
- Seat Cushion(s)
- High-Density (HC)


- Standard
- Optional

PRODUCT DIMENSIONS	OVERALL			SEAT			Arm Height	Open Depth	Wall Clearance
	Height	Width	Depth	Height	Width	Depth			
Power Recliner with Power Headrest -50PH	32"	41"	42"	20"	24"	21"	26"	66"	4"

Stocked Colors



Ash  
**749-01**  
Leather/Match



Coconut Milk  
**749-11**  
Leather/Match

*Printed samples may vary from actual swatches. Please refer to swatches for actual color.*

NOTES

Six sectional components available to create a custom configuration that fits your space, big or small

Wide, flat seat provides spacious comfort

Soft, wide contemporary track arms

Low and modern profile headrest powers up when in use

Low block wood leg is finished in a light, natural finish

The straight console includes two cupholders and a storage compartment for keeping belongings organized and tucked away

Available in two top grain leather color options that are durable for everyday use

Zero Gravity recline puts you in the ideal position that reduces pressure and gives you a feeling of weightlessness

Customize your comfort with a power control inside the arm that adjusts the headrest and recline independently

A home button on the power control returns the headrest and footrest to their original positions with one touch

USB-A and USB-C charging ports are built into power control for convenient charging and have zero draw technology to prevent the battery from draining when they're not in use

Built to last with our patented Flexsteel DualFlex Spring System—sturdy steel ribbons attached to flexible coils that offer a wide range of motion and durability

Power allows you to smoothly adjust the seat depths.

A single USB port is included on each power button control on styles with arms.

Power to the USB port is activated only when the port is in use.