



SAMSUNG

Unpacking and Installation Guide



USB	USB ↔	OPTICAL	
ARC	HDMI (eARC)	LAN	
	HDMI	ANT	



Scan this QR code with your smart phone to see helpful videos.

1 **77"**

83"

2


3

4 **77"**


83"

5


6





7



8




9



	A	B	C	D	E	F	G	H
77S9*H	67.7 inches (1718.5 mm)	38.9 inches (987.6 mm)	1.8 inches (44.9 mm)	41.7 inches (1058.6 mm)	14.1 inches (359.0 mm)	76.6 inches	71.4 lbs (32.4 kg)	75.4 lbs (34.2 kg)
83S9*H	72.9 inches (1851.0 mm)	41.8 inches (1062.8 mm)	1.8 inches (44.9 mm)	44.6 inches (1133.7 mm)	14.1 inches (359.0 mm)	82.5 inches	82.9 lbs (37.6 kg)	86.9 lbs (39.4 kg)

*: 0-9, A-Z



	VESA A x B (mm)	C (mm)	D	E x 4	F (mm)	G (inches)	H (inches)	I (inches)
77S9*H	400 x 300	28-30	C + ★	M8	1.25	24.0	26.0	3.1
83S9*H	400 x 300	28-30	C + ★	M8	1.25	26.9	28.6	3.1

*: 0-9, A-Z

★: Wall-Mount Bracket