
FLEXSTEEL®

Power Recliner with Power Headrest & Lumbar


IMPORTANT NOTE


Read these instructions carefully and familiarize yourself with each procedure before assembling the furniture. Check that you have all the component parts and familiarize yourself with each part before proceeding.


Take all the fittings out of the plastic bad and separate them into groups. Ensure you have enough space to lay out all the parts before assembly. To prevent damage to the parts, we recommend that you assemble the unit on a soft, level surface.



Part List








Assembly Instructions

STEP 1

Detach the Transformer (C) from the bottom of the Seat (B). (See Figure 1.)



STEP 3

Attach the Back (A) to the Seat (B). Ensure the latches fit well. (See Figure 3.)





Figure 3

STEP 5

Connect the base motor cable to the adapter and plug the Transformer (C) into a nearby outlet. (See Figure 5.)



STEP 2

Lay the Back (A) face down on the Seat (B).

Connect the headrest and lumbar cables. (See Figure 2.)




Figure 2

STEP 4

Zip the fabric on bottom of the Back (A) with back of Seat (B). (See Figure 4.)




Figure 4

Disassembly Instructions

Unzip the zipper between Back (A) and Seat (B), then disconnect the headrest cable. Pull up the spring leaf in bracket, then lift Back (A) up. (See Figure 7.)

