


UTTERMOST

ASSEMBLY INSTRUCTIONS

STYLE#: 30764

Carefully unpack all Assembly Parts from the carton.

1. Place the **Lamp Base** on a level surface.
2. Thread **Part A** into **Part B** by turning clockwise until snug.
3. Place the Shade over the top end of **Part A**. Secure by threading the Finial onto **Part A** and hand tighten until snug.
4. Install correct bulb referring to fixture markings and/or labels for maximum wattage.



IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.