

OZARK-WHITE-CH ASSEMBLY INSTRUCTION

Thank you for purchasing this quality product. Be sure any small parts and hardware not for children under 3 years.
Adult assembly required.


"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"

"DO NOT OVERTIGHT ANY HARDWARE"

PART LIST

ITEM	DESCRIPTION	DRAWING	QTY
1	CHEST		1 PC

HARDWARE LIST

ITEM	DESCRIPTION	DRAWING	QTY
A	TIPPING RESTRAINT		1 SET

ASSEMBLY STEPS



STEP 1

STEP 1.1: Turn loose all the handles and screws.


STEP 1.2: Exchange location of these items then tighten.

ASSEMBLY TOOLS REQUIRED


Screwdriver (not provide)



STEP 1.1




STEP 1.2




OZARK-WHITE-CH ASSEMBLY INSTRUCTION

STEP 2



STEP 3



ASSEMBLY COMPLETED