

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

722852
TV STAND

ITEM:722852

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

60 MINUTES

MAX TV SIZE : 65"











PARTS IDENTIFICATION



NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **722852****HARDWARE IDENTIFICATION****Z**


NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	9	HINGE SCREW Ø4x15mm SR		16 PCS
2	WOODEN DOWEL Ø8 x 30mm		31PCS	10	HANDLE L=120mm BLK		2 PCS
3	CAM BOLT Ø7 x 35.5mm SR		19 PCS	11	RAIL SCREW Ø 3x15mm BLK		11 PCS
4	CAM LOCK Ø15 x 12mm SR		19 PCS	12	PLASTIC COVER Ø 52mm		3 PCS
5	LONG SCREW Ø 4.5x42mm SR		9 PCS	13	FOOT Ø35 x H19mm		6 PCS
6	PIN FOR ADJUSTABLE SHELF Ø4.9x8mm SR		8 PCS	14	SCREW DRIVER		1 PC
7	DOOR CATCH		2 PCS	15	STICKER Ø20mm		4 PCS
8	HINGE Ø35mm SR		4 PCS				

Z8, Z10, Z12, Z13 not included in blister packaging.**NOTE:**


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **722852**

STEP 1







STEP 2







ITEM: **722852**


STEP 3



STEP 4




INCORRECT
CORRECT




Apply glue on all wooden dowels to ensure integrity of the structure.

ITEM: **722852**




STEP 5







INCORRECT
CORRECT



Apply glue on all wooden dowels to ensure integrity of the structure.





STEP 6






ITEM: **722852**

STEP 7





STEP 8





ITEM: **722852**

COASTER
FINE FURNITURE

STEP 9





STEP 10





ITEM: **722852**

COASTER
FINE FURNITURE

STEP 11





STEP 12




ITEM: **722852**

STEP 13

COASTER
FINE FURNITURE




STEP 14




ITEM: **722852**

COASTER
FINE FURNITURE

STEP 15





STEP 16






ITEM: **722852**

STEP 17

COASTER
FINE FURNITURE






STEP 18




ITEM: **722852**

COASTER
FINE FURNITURE

STEP 19




STEP 20




ITEM: **722852**


STEP 21






HORIZONTAL BY
SCREW AADJUSTMENT









LATERAL BY
SCREW B ADJUSTMENT



VERTICAL BY
SCREW C ADJUSTMENT



STEP 22






ITEM: **722852**




STEP 23

COMPLETE



ITEM: 722852



Note : Dimension tolerance $\pm 5\%$