





ASSEMBLY INSTRUCTIONS




LIST OF PARTS


TOOLS REQUIRED:NO TOOLS REQUIRED

PART LIST


NO	Description	Item	Quantity
A	PWR RECLINER WITH PHR Backrest		1
B	PWR RECLINER WITH PHR Seat		1
C	wall plug transformer		1



ASSEMBLY INSTRUCTIONS



MANUAL CONTROLS



1. Press button **1** to recline the chair to desired position.
2. Press button **2** to raise the chair to the upright position.
3. Press button **3** to activate the headrest forward.
4. Press button **4** to return headrest to the closed position.
5. Press button **5** Home button returns both footrest and headrest to the original upright/closed position.