

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

223524
Mirror

ITEM: **223524**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A MIRROR




1PC

**B MIRROR SUPPORT
(PACKED WITH MIRROR)**



2PCS

**C DRESSER
* FROM BOX ITEM# 223523**



1PC


HARDWARE IDENTIFICATION

**1 ALLEN WRENCH
(Φ6 - ZINK)**



1PC

**2 BOLT
(Φ6 X 40mm - RBW)**



8PCS

**3 LOCK WASHER
(Φ6 - RBW)**



8PCS

**4 MEDIUM FLAT WASHER
(Φ7 X 19mm X 2.0 - RBW)**



8PCS

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **223524**




ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2



STEP 3
COMPLETE



ITEM: 223524



Note : Dimension tolerance $\pm 5\%$