



Electrolux

Factory Parts Catalog

Product No.	E30WV60PPSA	E36WV60PPSA
Market	North America	North America
Color	stainless steel	stainless steel
Exhaust-CFM	600 CFM	600 CFM
Volts	120	120
Owner's Guide	316902932en	316902932en
Installation Instructions	316902932	316902932
Wiring Diagram	316902933	316902933



Electrolux Major Appliances

P.O. BOX 8020
CHARLOTTE, NC 28262


**This Publication Replaces
Publication # 5995656120**

Publication No.
5995701181
18/04/18
(EN/SERVICE/ECL)
099

RANGE HOOD

Model No.
E30WV60PP /
E36WV60PP

REPLACEMENT PARTS



E30WV60PPSA-Parts

REPLACEMENT PARTS

Model Index: **A** E30WV60PP (E30WV60PPSA)
 B E36WV60PP (E36WV60PPSA)

POS. NO	PART NO.		DESCRIPTION
19 #	5304464261	A B	Capacitor
23 #	5304492981	A -	Filter, grease, 322 x 344mm, aluminum
23 #	5304504064	- B	Filter, grease, 322 x 420mm, aluminum
31 #	5304466038	A B	Lamp, halogen, 50 W, 120 V
36 #	5304492982	A B	Lamp Holder, socket, w/housing
103#	5304492983	A B	Motor Assembly, with fan blade
234#	5304487843	A B	Switch, motor, rotary
235	5304487844	A B	Knob, motor switch
236	5304487845	A B	Knob, light switch
519	5304492984	A B	Use & Care w/Instl Hardware
558#	5304487842	A B	Switch, light/lamp, rotary
573	5304487849	A B	Bezel, lamp assembly
586	5304490028	A B	Damper, vent, 3-1/4" x 10"

WIRING DIAGRAM

