

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

603303P Power Recliner

## ITEM: 603303P

#### **ASSEMBLY INSTRUCTIONS**



#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES

## **PARTS IDENTIFICATION**

A BACK




1PC

B SEAT



1PC

C ADAPTER



1PC

D POWER CABLE



1PC


## ITEM: 603303P

### C


#### **ASSEMBLY INSTRUCTIONS**

#### STEP 1







#### STEP 2



# STEP 3 COMPLETE







COASTERFURNITURE.COM

# ITEM: 603303P







**Note: Dimension tolerance ±5%**