
















Assembly Instruction For ROUND BACK COUNTER STOOL D-1710-8-CST2

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.


1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts.
4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PART LIST				
No.	PART DESC		CODE.	Q'TY
A	BACK COUNTER		PD-1710-8-CBST2BAC	1
B	SEAT CUSHION WITH FRAME		PD-1710-8-CBSTSEA	1
C	LHF LEG FRAME		PD-1710-8-CSTLEGL	1
D	RHF LEG FRAME		PD-1710-8-CSTLEGR	1
E	BACK STRETCHER		PD-1710-8-CBSTSTR1	1
F	FRONT STRETCHER WITH METAL PLATE		PD-1710-8-CBSTSTR2	1

HARDWARE LIST				
NO.	HARDWARE DESC		CODE.	Q'TY
1		ALLEN BOLT (1/4"x 3-1/4")	PD-1710-8-CBSTHW	4
2		ALLEN BOLT (1/4"x 1-3/4")		2
3		ALLEN BOLT (1/4"x 1-1/2")		4
4		SPRING WASHER(1/4")		8
5		FLAT WASHER (1/4"x 7/8")		8
6		WOOD SCREW (#8x 1-1/2")		4
7		WOOD SCREW (#8x 2")		2
8		NUTS		2
9		ALLEN KEY(M4)		1


 Only tighten all bolts when all bolts aligned with bolt inserts.

STEP : 1




Assembly Instruction For
ROUND BACK COUNTER STOOL
D-1710-8-CST2

STEP : 2



STEP : 3



COMPLETED

