

ASSEMBLY INSTRUCTION


ITEM NUMBER : B7300-1 / B7350-1

DESCRIPTION : DRESSER




Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have loose inside the carton during shipment. Identify and count all parts and compare with the parts list below.

PART LIST#

NO	DRAWING	DESCRIPTION	QTY
A		Dresser	1pc
B		Leg	4pcs
C		Center Leg	1pc



Remove Leg carton located in the drawer of the casegood. Remove and unwrap each leg.



THE HARDWARE IS LOCATED IN THE PACKING ITEM


THE ANTI TIPPING HARDWARE IS LOCATED IN THE 1ST RIGHT SIDE FRONT DRAWER OF DRESSER


Note: Periodically check to ensure that all connectors (bolts,screw,etc.) are tight.

CLEANING INSTRUCTION

After assembly, clean & polish the completed parts if necessary with softcloth and industrial recognized furniture polish

HARDWARE LIST (ANTI TIPPING)

NO	NAME	PART	QTY
A	Bracket		2pcs
B	Tie Wrap		1pc
C	Long Screw		1pc
D	Short Screw		1pc



Assembly completed