

INSTRUCTION SHEET

U400652
U400A652

SIENNA RECTANGULAR DINING TABLE
CANYON RECTANGULAR DINING TABLE

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.

Caution: (1) These parts are cumbersome and heavy. This product can best be assembled with the assistance of one or more persons in order to prevent personal injury and to insure parts are not damaged during the assembly process. If dirty, clean finished parts with mild dishwashing liquid and water solution applied on a damp cloth. The cloth should not be excessively wet. Polish finish with a soft cloth and an industry recognized furniture polish.

(2) To prevent damage to your floor or carpet, please check the bottom of each piece of furniture for stain residue and rough surfaces and also check for staples or nails left after removing the packaging material. The manufacturer will not be held responsible if preventative steps are not taken prior to installation.

(3) Unpack and dispose of all packing material but be careful not to throw away any assembly parts or hardware. Read the instruction sheet and parts list carefully. Remove all staples and screws used for packaging carefully using pliers and or screwdrivers to prevent injury and scratching or damaging flooring.

(4) During normal use everyday, screws, bolts, nuts and wooden plugs may loosen up. They should be periodically inspected and re-tightened to prevent damage to the furniture and (or) personal property or cause injury. Always check to be sure all hardware on this list and the above mentioned components is attached to the furniture properly and kept tightened at all times.

PARTS LIST:

| # | Description | Qty. | # | Description | Qty. |
|----------|-------------------|------|----------|-------------|------|
| A | Dining Table Top | 1pc | B | Legs | 2pcs |
| C | Bottom Stretchers | 2pcs | D | Table Leaf | 1pc |
| E | Leaf bag | 1pc | | | |

Assembly Procedure: (Please follow the sketches below).

Unpack, inspect, and read assembly instruction carefully. Lay out the parts and hardware. Make sure the quantity of each is correct.

Step 1: Attach the legs (B) in the direction of the arrow to table top (A) using Hex head Bolt (3), Spring Washer (4) and Flat Washer (5). Tighten with Wrench (6).

Step 2: Attach the Bottom Stretchers (C) to the legs (B) using Hex head Bolt (1), Spring Washer (4) and Flat Washer (5). And then attach Bottom Stretchers (C) to the table top (A) using Hex head Bolt(2), Spring Washer (4) and Flat Washer (5). Secure all bolts by screwdriver (not provided) as sketch.

Step 3: Turn the table upright. Unlock table top (A), take off the table leaf (D) and put it in leaf bag (E) when Leaf is not in use. Then lock the table top. Use adjustable leveler as necessary.



Note: If handled improperly, the act of installing and removing table leaf may damage the table. Please use caution and delicate handling when installing and removing table leaf to prevent damaging the table top surface and edges. It is best two persons are involved when installing or removing table leaf.

Assembly is now complete.

INSTRUCTION SHEET

U400652
U400A652

SIENNA RECTANGULAR DINING TABLE
CANYON RECTANGULAR DINING TABLE



| HARDWARE LIST | | | Q'TY |
|---------------|----------------|------------------|--------|
| 1 | HEX HEAD BO LT | Ø5/16" x 3" | 2 PCS |
| 2 | HEX HEAD BO LT | Ø5/16" x 2" 3/16 | 2 PCS |
| 3 | HEX HEAD BO LT | Ø5/16" x 1" 3/4 | 8 PCS |
| 4 | SPRING WASHER | Ø5/16"xØ12x1.5mm | 12 PCS |
| 5 | FLAT WASHER | Ø5/16"xØ19x1.5mm | 12 PCS |
| 6 | WRENCH | 12mm | 1 PC |

