

DENON®

AVR-S500BT

AV SURROUND RECEIVER

Quick Start Guide

Read Me First....

Guide de configuration rapide / Guía de configuración rápida /

Guia de Arranque Rápido

Lisez-moi en premier.... / Lea esto primero.... /

Leia isto primeiro....

ENGLISH

FRANÇAIS

ESPAÑOL

PORTUGUÊS

Please do not return this unit to the store – call for assistance.

If you need help... :

If you need additional help in solving problems, contact Denon customer service in your area.

1-855-MY.Denon

1-855-693-3666

Call for Assistance:

Monday – Friday 10:00AM to 10:00PM E.S.T

Saturday 12:00PM to 8:00PM E.S.T

For frequently asked questions please visit

www.usa.denon.com/FAQ


For US and Canada only

Welcome

Thank you for choosing a Denon AV receiver. This guide provides step-by-step instructions for setting up your AV receiver.

Before You Begin


Required for Setup




TV



HDMI cable



Speaker systems



Speaker cables



- When connecting this unit to a device that is compatible with the Deep Color and 4K, use a “High Speed HDMI cable with Ethernet” that comes with the HDMI logo.
- These drawings are for illustrative purposes only and may not represent the actual product(s).

What's In the Box

Quick Start Guide		FM indoor antenna	
Safety Instructions		AM loop antenna	
Notes on radio		Remote control unit	
Warranty (for North America model only)		R03/AAA batteries	
Receiver		Sound calibration microphone	



The supplied Sound calibration microphone stand is convenient for use when performing Speaker Calibration. Using your own tripod or the supplied Sound calibration microphone stand enables settings to be automatically configured to the optimum listening environment, providing exceptionally high performance.

Setup



There are three steps to the setup process.

1 Install batteries in the remote control unit

2 Connecting the receiver


3 Follow the On-Screen Setup Assistant

1 Installing batteries in the remote control unit




2 Connecting the receiver



- ❑ Place the receiver near your TV and connect the power cable.



- ❑ **Connect the receiver to your TV with an HDMI cable.**





- ❑ **Turn on the TV.**



TV remote control unit


- ❑ **Select the appropriate HDMI input on your TV.**



TV remote control unit


❑ Turn on the receiver.

- Press  to turn on the receiver.



❑ Verify the connection.



- Verify that you can see this screen on your TV.



When this screen is not displayed, please read operation from the beginning.

3 Follow the On-Screen Setup Assistant

The Setup Assistant will walk you through connecting and configuring your speakers and components to your Denon receiver. Please use the remote control and follow the on-screen instructions.




Owner's Manual

- For more information, visit www.denon.com.
- Refer to the Web Manual for other functions information and operation procedure details.
manuals.denon.com/AVRS500BT/NA/EN/



Web Manual



DENON®

www.denon.com

D&M Holdings Inc.
Printed in China 5411 11181 04AD