


**Warning :**

- Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment.
- To prevent possible scratches and damage, this furniture must be assembled on a soft surface such as a blanket or carpet.




#50558  
Uphost Chair 2In

**Components and Hardware List**

<p>Chair Back 1 pc.</p> <p>(A)</p>	<p>Front Leg 2 pcs.</p> <p>(B)</p>	<p>Back Leg 2 pcs.</p> <p>(C)</p>	<p>Allen Head Bolt Ø5/16" - 18 x 2"</p> <p>(D) 8 pcs.</p>	<p>Spring Washer 5/16"</p> <p>(E) 8 pcs.</p>
<p>Flat Washer 5/16" x 19 x 2mm</p> <p>(F) 8 pcs.</p>	<p>4mm Allen Key</p> <p>(G) 1 pc.</p>			

Step 1



Step 2

