


Assembly Instructions

CM7684CK/EK/Q



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.


EASY




DIFFICULT

Tools Required For Assembly:



Allen Wrench



Wrench



Phillips Screwdriver




2 PERSONS RECOMMENDED


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.




Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

Parts List




#1 x 1pc
Headboard



#2 x 1pc
Right H/Board Leg



#3 x 1pc
Left H/Board Leg



#4 x 1pc
Leg Support



#5 x 3pcs
Support Rail Leg




#6 x 1pc
Left Side Rail



#6 x 1pc
Right Side Rail




#7 x 10pcs
Slat



#8 x 1pc
Footboard W/Drawers



#9x 1pc
Support Rail



Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

Hardware List



#A x 4pcs
Threaded Stud 5/16" x 3"



#B x 4pcs
Side Rail Bracket



#C x 4pcs
Large Lock Washer



#D x 4pcs
Hex Nut



#E x 1pc
Wrench



#F x 20pcs
Short Screw Ø9 x 1"




#G x 8pcs
Bolt 5/16"x1"



#H x 8pcs
Flat Washer




#I x 8pcs
Small Lock Washer




#J x 2pcs
Bracket



#K x 1pc
Allen Wrench



#L x 2pcs
Long Screw Ø9 x 1-1/2"



Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

Hardware List



#A x 4pcs
Threaded Stud 5/16" x 3"



#B x 4pcs
Side Rail Bracket



#C x 4pcs
Large Lock Washer



#D x 4pcs
Hex Nut



#E x 1pc
Wrench



#F x 20pcs
Short Screw Ø9 x 1"



#G x 8pcs
Bolt 5/16"x1"



#H x 8pcs
Flat Washer



#I x 8pcs
Small Lock Washer



#J x 2pcs
Bracket



#K x 1pc
Allen Wrench




#L x 2pcs
Long Screw Ø9 x 1-1/2"




#1



#G x 8pcs
#H x 8pcs
#I x 8pcs
#J x 2pcs
#L x 2pcs



#2

#A x 4pcs
#B x 4pcs
#C x 4pcs
#D x 4pcs







#F x 20pcs

