

# Microwaves

FFCE1439L W/B

## Countertop



### Product Dimensions

|        |         |
|--------|---------|
| Height | 12-7/8" |
| Width  | 21-3/4" |
| Depth  | 18-1/2" |

### More Easy-To-Use Features

#### Effortless™ Reheat

Reheat almost anything at the touch of a button.

#### Multi-Stage Cooking

Our Multi-Stage Cooking option allows you to program power levels and cooking times in advance, so you can program it to defrost, cook and keep a meal warm all at once.

#### 10 Cooking Power Levels

Provides the versatility needed to prepare everything from frozen pizza to pot roast quickly and easily.

#### Control Lock Option

#### Electronic Clock/Timer

Helps you keep track of cook times.

#### Interior Light

Illuminates the contents of the microwave for increased visibility.

#### Large Glass Turntable

Even large items fit on our large glass turntable.

Available in:



## Signature Features

### Easy-Set™ Start

Quickly start cooking - one to six minutes - with just one touch.

### Ready-Select® Controls

Easily select options with the touch of a button.


### Sensor One-Touch Options

Microwave automatically adjusts power levels and cooking times to cook a variety of items, effortlessly.

### Effortless™ Defrost

Makes it easy to defrost almost anything, quickly and evenly.

| Features  |                   |
|---|-------------------|
| Control/ Timing System                              | Ready-Select®     |
| Exterior Door Finish                                | Color-Coordinated |
| Handle Design                                       | Push Button       |
| Microwave Features                                  |                   |
| Microwave Capacity (Cu.Ft.)                         | 1.4               |
| Watts (IEC-705 Test Procedure)                      | 1,100             |
| Interior Light                                      | Yes               |
| Interior Color                                      | White             |
| Turntable Diameter                                  | 14-3/16"          |
| Turntable On/Off                                    |                   |
| Control Lock  | Yes               |
| Clock   | Yes               |
| Touch Pad Buttons                                   | 23                |
| Power Levels  | 10                |
| Accessory Metal Rack                                |                   |
| Microwave Control Options                           |                   |
| Easy-Set™ Start                                     | Yes               |
| Popcorn Button                                      | Yes               |
| Chicken Nugget Button                               |                   |
| Baked Potato Button                                 | Yes               |
| Sensor Reheat Button                                | Yes               |
| Snack Button  |                   |
| Beverage  | Yes               |
| Melt & Soften Options                               |                   |
| Auto Reheat Options                                 |                   |
| Snack Menu Options                                  |                   |
| Auto Cook Options                                   | Yes               |
| Auto Defrost Options                                | Yes               |
| Keep Warm   | Yes               |
| Add-30-Seconds                                      | Yes               |
| Sensor Cooking Options                              | 7                 |
| Vegetable Cook Sensor                               | Yes               |
| Delay Start   |                   |
| User Preferences                                    |                   |
| Power Ratings                                       |                   |
| Frequency (Mhz)                                     | 2,450             |
| Watts @ 120 Volts                                   | 1,100             |
| Amps @ 120 Volts                                    | 13                |
| Specifications                                      |                   |
| Oven Interior Height                                | 10-5/16"          |
| Oven Interior Width                                 | 17-1/4"           |
| Oven Interior Depth                                 | 15-3/8"           |
| Power Supply Connection Location                    | Rear              |
| Voltage Rating                                      | 120V/60Hz/15A     |
| Connected Load (kW Rating) @ 120 Volts <sup>1</sup> | 1.55              |
| Minimum Circuit Required (Amps)                     | 15                |
| Shipping Weight (Approx.)                           | 44 Lbs.           |



NOTE: For planning purposes only. Always consult local and national electric codes. Refer to Product Installation Guide for detailed installation instructions on the web at [frigidaire.com](http://frigidaire.com).



| Product Dimensions <sup>1</sup> |         |
|---------------------------------|---------|
| A - Height                      | 12-7/8" |
| B - Width                       | 21-3/4" |
| C - Depth                       | 18-1/2" |

<sup>1</sup>A minimum clearance of 3 inches is required between microwave oven and adjacent walls. Leave a minimum clearance of 12 inches above microwave oven.

Accessories information available on the web at [frigidaire.com](http://frigidaire.com)