


PARTS LIST / LISTE DES PIÈCES / LISTA DE PIEZAS

ITEM / NO D'ARTICLE / ARTICULO : S910-010/030

DESCRIPTION / DESCRIPTION: Dresser - Commode - Tocador

Beveled Mirror w/ LED Lights - Miroir avec Éclairage à Del - Espejo con Iluminación Led

	WARNING Children have died from furniture tipover. To reduce the risk of furniture tipover: · ALWAYS Anti-tip device provided. · NEVER put a TV on this product. · NEVER allow children to stand, climb or hang on any drawers, doors, or shelves. · NEVER open more than one drawer at a time. · PLACE heaviest items in the lowest drawers. This is a permanent label. Do not remove !




A

- x1 Dresser
- x1 Commode
- x1 Tocador




B

- x2 Front Leg *
- x2 Table de chevet
- x2 Mesa de noche



C

- x2 Back Leg *
- x2 Table de chevet
- x2 Mesa de noche




D

- x1 Mirror
- x1 Miroir
- x1 Espejo



E

- x1 Center support leg *
- x1 Support central
- x1 Soporte para la pata centra



F

- x2 Mirror Support *
- x2 Supporte de miroir
- x2 Soporte del espejo



G

- x1 Furniture Tipping Restraint *
- x1 Systeme antibasculement
- x1 Control para evitar vulecos



1

- x8 Allen bolt Ø5/16"x18x50mm*
- x8 Vis à tête creuse hexagonale Ø5/16"x18x50mm
- x8 Perno Allen Ø5/16"x18x50mm



2

- x8 Lock washer Ø5/16" *
- x8 Rondelle de blocage Ø5/16"
- x8 Arandela de Seguridad Ø5/16"



3

- x8 Flat Washer Ø5/16"x19x1.5mm*
- x8 Rondelle plate Ø5/16"x19x1.5mm
- x8 Arandela plana Ø5/16"x19x1.5mm



4

- x8 Allen bolt Ø1/4"x35mm*
- x8 Vis à tête creuse hexagonale Ø1/4"x35mm
- x8 Perno Allen Ø1/4"x35mm




5

- x8 Lock washer Ø1/4" *
- x8 Rondelle de blocage Ø1/4"
- x8 Arandela de Seguridad Ø1/4"



6

- x8 Flat Washer Ø1/4"x1.5mm*
- x8 Rondelle plate Ø1/4"x1.5mm
- x8 Arandela plana Ø1/4"x1.5mm




7

- x1 Allen Key 4mm*
- x1 Clé hexagonale 4mm
- x1 Llave Allen 4mm


**Replaceable Part*

	
WARNING Children have died from furniture tipover. To reduce the risk of furniture tipover: · ALWAYS Anti-tip device provided. · NEVER put a TV on this product. · NEVER allow children to stand, climb or hang on any drawers, doors, or shelves. · NEVER open more than one drawer at a time. · PLACE heaviest items in the lowest drawers. This is a permanent label. Do not remove !	

STEP 1





STEP 2




**Replaceable Part*

WARNING Children have died from furniture tipover. To reduce the risk of furniture tipover: · ALWAYS Anti-tip device provided. · NEVER put a TV on this product. · NEVER allow children to stand, climb or hang on any drawers, doors, or shelves. · NEVER open more than one drawer at a time. · PLACE heaviest items in the lowest drawers. This is a permanent label. Do not remove !	



STEP 3




STEP 4

Replaceable Part


	WARNING Children have died from furniture tipover. To reduce the risk of furniture tipover: · ALWAYS Anti-tip device provided. · NEVER put a TV on this product. · NEVER allow children to stand, climb or hang on any drawers, doors, or shelves. · NEVER open more than one drawer at a time. · PLACE heaviest items in the lowest drawers. This is a permanent label. Do not remove !
	



x9 RS910-010-KNOB- Knob with Screw*
Poignée + vis
Tirador + Tornillo




x2 RS910-010-FLEG-From Leg
Pate
Pata



x2 RS910-010- BLEG-Back Leg
Pate
Pata



x9 COMGLIDE-10-45- Common Glide 10in-45mm*
Tiroir Glide
Deslizamiento del cajón




x2 RS910-030-MISL- Mirror Support*
Supporte de miroir
Soporte del espejo



x1 RC-ANTL-TIP- Anti-tipping restraint
Liste des pièces de quincaillerie antibascullement
Lista del kit de materiales antivuelco




x1 RS910-010-HWKIT-Hardware kit list
Liste des pièces de quincaillerie
Lista del kit de materiales



x1 RS910-030-HWKIT-Hardware kit list
Liste des pièces de quincaillerie
Lista del kit de materiales




x1 RS910-010-CELEG- Center support leg
Support central
Soporte para la pata central



x2 RC-WH-NAIL- White plastic nail
Clou en plastique
Clavo de plástico




x3 RC-FG-WHITE- White leveler
Patin réglable
Nivelador ajustable



x1 RS910-030-LIGHT-Light
Luminaire
Lámpara



x1 RS910-030-BRACKET-Bracket with Screw*
L. Ferrure et vis
L. Ménsula y Tornillo



* Replaceable Part

Protect Your Wood or Laminate Flooring

***This statement applies to any floor without carpet.**

If not careful, all furniture including upholstery and case pieces can scratch, scuff and even gouge floors. The recommendation is to have felt, rubber pads or area rugs under furniture on flooring without carpet.

Moving your furniture

Pushing and dragging furniture over floors without carpet can lead to scratches and scuffs. Have someone help when moving the larger pieces of furniture by lifting, try using a dolly or moving pads.

Felt and rubber pads

Applying furniture pads to the feet of furniture helps cushion contact points. Furniture pads can be found at local hardware stores. Felt pads slide easily across the floor, making them ideal for dining chairs and other pieces that move with use. Rubber pads will help furniture stay in place and are perfect for larger pieces, like sofas and loveseats.

Area rugs and rug pads

Using an area rug under furniture is another way to protect your floor from scratches and scuff marks. A rug pad under the area rug will provide extra cushion and added protection.