




RACK CARTRIDGE

USER MANUAL

CR13U/A	13U	Cartridge Rack Mount System for 30" Cabinet, Adjustable Depth 16-20"
CR13U/F	13U	Cartridge Rack Mount System for 30" Cabinet, Fixed Depth
CR7U/A	7U	Cartridge Rack Mount System for 20" Cabinet, Adjustable Depth 16-20"
CR7U/F	7U	Cartridge Rack Mount System for 20" Cabinet, Fixed Depth




CAPACITY

200lbs

PARTS


ID	QTY	PART NUMBER	DESCRIPTION
	(1)	PHK-635 (bag)	
A	(38)	300-485	1/4-20 x 1/2" Button Head Screw
B	(5)	300-518	1/4-20 x 3/8" Button Head Screw
C	(7)	300-565	Drop-in Nut
D	(1)	301-510	1/4-20 x 1" Set Screw
E	(1)	300-530	Thumb Nut 1/4-20
F	(2)	302-315	10-32 x 1/2" Button Head Cap Screw (fasten wire manager)
G	(2)	300-468	1/4" SAE Flat Washer (wire manager)
H	(1)	400-070	5/32" Hex wrench
I	(1)	400-080	1/8" Hex wrench
J	(1)	400-080	5/32" Assembly Bit (for use in drill)

K	(2)		Vertical Rack Bracket - Left
L	(2)		Vertical Rack Bracket - Right
M	(1)	301-482	Cartridge Guide Rail (Hinge Side)
N	(1)	301-484	Cartridge Guide Rail (Non-Hinge Side)
O	(2)	303-300	Vent Grill
P	(1)		Rack Base
Q	(1)		Rack Top




Remove door

Remove door using quick release tab at the back of hinges (circled below)




Install Guide Rails

Install the hinge side guide bracket to extrusions under the hinge base (as shown below). For Chameleon series cabinets use 3/8" (B) screw and for Synergy cabinets use the 1/2" (A) screw with drop-in nut (C).




Using the same fasteners, install flat Guide Rail bracket to the opposite side with screw holes closest to the cabinet bottom panel (as shown below).





Adjust Cartridge Depth

For adjustable depth racks, adjust the depth to the desired dimension in 1" incremental positions of the hole pattern on the side of the rack top and bottom.




Attach Vertical Rails

Attach vertical rails to the base with screws (A). Be sure arrow is indicating the top of the unit*. Install all screws before tightening.




Attach Top Panel

Attach top panel to vertical rails by holding top panel in position and securing each side with one screw. Follow up by securing each corner with the remaining 3 screws.




Install Vent Grills




Install Wire Manager

Using thumb nut, washer, stud, and EZ nut, install wire manager to rear extrusion near top of cabinet. Using 10-32 screw and washer attach the other end to the rack. Multiple wire managers may be used to separate or achieve necessary capacity of wires needed.




Install Cartridge Into Cabinet

1. Push Rack into cabinet lifting slightly as front wheels touch cabinet bottom panel.
2. Release locking levers and continue to push rack into cabinet until levers engage.




3. Remove rack, install gear and reinstall to cabinet.



Reattach door

1. Clip hinge onto front of hinge back
2. Press back of hinge to fix (click).



LIMITED WARRANTY FOR COMMERCIAL VIDEO DISPLAY STANDS AND MOUNTS

Salamander is proud to stand behind our products with industry-leading warranties. Should you ever encounter any problem with your Salamander product, let us know. We are here to make it right. 1.800.535.5659 - 860.761.9500

Full warranty including limitations and warranty claim information may be found at www.salamanderdesigns.com/commercial/warranty