



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

193781
DINING TABLE

REVISION 0 : 01/21/2022
REVISION 1 : 03/16/2022

PAGE 1 OF 5

COASTERFURNITURE.COM

ITEM:193781



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME 25 MINUTES

PARTS IDENTIFICATION


B1: DINING TABLE TOP

AN TOP PANEL



1PC


D SUPPORT CROSSBAR



2PCS


B2: DINING TABLE BASE

B LARGE FRAME



1PC

C LEG



2PCS





ITEM:193781






ASSEMBLY INSTRUCTIONS

ZN

HARDWARE IDENTIFICATION


1	BOLT (1/4" x 15mm BLK)		16PCS
2	LEVELER (5/16" x 15mm BLK)		4PCS
3	SPRING WASHER (1/4")		16PCS
4	WASHER (1/4")		16PCS

5	SCREW 3.5 x 38mm		8PCS
6	CAP 13 x 26mm		4PCS
7	ALLEN WRENCH (4mm)		1PC


Hardware pack is located in 193781B2

STEP 1

Do not tighten until each step is completed or instructed.




STEP 2





ITEM:193781

ASSEMBLY INSTRUCTIONS

STEP 3



STEP 4 COMPLETE




ITEM:193781

ASSEMBLY INSTRUCTIONS



Product Size : 2210 X 1092 X 762 H (MM)
Product Size : 87" X 43" X 30"



Note : Dimension tolerance $\pm 5\%$