


B E R N H A R D T


LIVING

BLISS PLUSH SECTIONAL




P7430 ARMLESS CHAIR

W 37 | D 40 | H 28 in.
SH 15.50 | SD 25.50 in.




P7432 CORNER CHAIR

W 39.50 | D 39.50 | H 28 in.
SH 15.50 | SD 25 in.




P7431 OTTOMAN

W 40 | D 40 | H 15.50 in.



P7442 LEFT ARM LOVESEAT

W 84 | D 40 | H 28 in.
SH 15.50 | AH 28 | SD 25.50 in.



P7441 RIGHT ARM LOVESEAT

W 84 | D 40 | H 28 in.
SH 15.50 | AH 28 | SD 25.50 in.