


Setup Guide

Téléviseur
Televisor digital a color con pantalla de diodo orgánico
de emisión de luz (OLED)
Televisor



5-057-739-13(1)



EN	Setup Guide
FR	Manuel de configuration
ES	Guía de configuración
PT	Guia de Configuração

Sony Customer Support
U.S.A.:
<https://www.sony.com/tvsupport>
Canada:
<https://www.sony.ca/support>
U.S.A. 1.800.222.SONY (7669)
Canada 1.877.899.SONY (7669)
Please Do Not Return the Product to the Store

Service à la clientèle Sony
Canada :
<https://www.sony.ca/support>
États-Unis :
<https://www.sony.com/tvsupport>
Canada 1.877.899.SONY (7669)
États-Unis 1.800.222.SONY (7669)
Ne retournez pas le produit au magasin

Lea este manual antes de usar el producto

Centro de Asistencia de Sony
<https://esupport.sony.com/ES/LA/>
Llame al número telefónico que aparece en
su póliza de garantía.
Por favor no devuelva el producto a la tienda
donde adquirió el producto.

BRAVIA

K-77XR80 / 77XR80C / 77XR8B
K-77XR8C / 65XR80 / 65XR80C
K-65XR8B / 65XR8C / 55XR80
K-55XR80C / 55XR8B / 55XR8C

1

SB

CN

IM

65 55

SB

CN

M5L16

CD

★1

★1★2

77

65

55

1.5 N·m/1,5 N·m
(15 kgf·cm)

2

3

★1

55

77

65

4

5

①

②

SB

M5L16

④

⑤

SB

M5L16


6

★1 Only for limited region/country/model. / Uniquement pour certaines régions/pays/modèles. / Solo para regiones/países/modelos limitados. / Exclusivo para regiões/países/modelos especificados.


★2 Refer Reference Guide. / Reportez-vous au Manuel de référence. / Consulte la Guía de referencia. / Consulte o manual de instruções.

© 2024 Sony Corporation


7




8






9




10




11




*3




*4



*5



*6



*7

