





CROSLEY

FURNITURE



Counter Stool CF502726



PART LIST


A 	B 	C 
Seat 2 PCS	Left Leg 2 PCS	Right Leg 2 PCS

HARDWARE LIST

#1  Ø1/4"x1"	#2  Ø1/4"x1/2"	#3 	#4 	#5 
Long Bolt 12 PCS (Extra 1)	Short Bolt 8 PCS (Extra 1)	Spring Washer 8 PCS (Extra 1)	Flat Washer 8 PCS (Extra 1)	Allen Wrench 1 PC

Step 1. Attach left leg (part B) to right leg (part C) using long bolts (part #1) and allen wrench (part #5).


NOTE: Please do not fully tighten bolts until unit is fully assembled.



Step 2. Lay seat (part A) upside down on a soft flat surface, such as carpet.

Attach assembled unit (parts B & C) to seat (part A) using short bolts (part #2), spring washers (part #3), flat washers (part #4) and allen wrench (part #5).

NOTE: Please fully tighten all bolts at this time.



Step 3. Carefully turn unit upright. Repeat steps 1-2 to assemble remaining stool.

NOTE: It is important to adjust levelers once fully assembled and upright. Extend adjustable leveler until it's firmly in contact with the floor. If relocating, adjust levelers as needed until it's firmly in contact with the floor in new location.

