

WINNERS ONLY®






Assembly Instructions


DFGT145224

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing. Please keep all hardware parts out of the reach of children.

- 1) We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to person during assembly.
- 2) Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
- 3) Please do not over tighten screws or bolts.
- 4) Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PARTS LIST

PART NO	FIGURE	DESCRIPTION	Q'TY
DFGT145224-01		Hardware Bag	1 Pc
DFGT145224-02		Chair Back	1 Pc
DFGT145224-03		Cushion Seat	1 Pc
DFGT145224-04		Front Leg (Right)	1 Pc
DFGT145224-05		Front Leg (Left)	1 Pc
DFGT145224-06		Side Stretcher (Left)	1 Pc
DFGT145224-07		Side Stretcher (Right)	1 Pc
DFGT145224-08		Front Stretcher	1 Pc



WINNERS ONLY®

Assembly Instructions

DFGT145224


HARDWARE PARTS :

						
JCBC Bolt 80mm 4 pcs	JCBC Bolt 63mm 4 pcs	JCBC Bolt 40mm 3 pcs	Lock Washer 11 pcs	Flat Washer 11 pcs	Wood Screw 6 pcs	Allen Key 1 pc


Step 1: Attached Cushion Seat to the Chair Back using the provided hardware as shown on Fig. 1.1 and Fig. 1.2.

Step 2: Attached Front Legs (Left and Right) to Cushion Seat and the Side and Front Stretchers to Front Legs and Chair Back using the provided hardware as shown in Fig. 2.1 and Fig. 2.2

STEP 1




STEP 2



STEP 3

Turn the chair to standing position. Check it's balance and tighten all screw and bolt to complete the assembly.



CARE INSTRUCTION

- Be sure to use the same type of polish consistently. Your furniture will appear cloudy or streaky if oil based or wax based polishes are interchanged.
- Spray your furniture surface evenly. Wipe in a circular motion with a soft clean cloth.