

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

603252PP Dual Power Loveseat

REVISION 0: 07/21/2025

PAGE 1 OF 5

COASTERFURNITURE.COM



ASSEMBLY INSTRUCTION

ASSEMBLY TIPS:


- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts a represent prior to start of assembly.
- 3.Please follow attached instruction in the same sequenceas numbered to assure fast & easy assembly.



WARNING!

1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A SEAT BODY



1PC B ADAPTER 1



1PC

C LEFT BACKREST



1PC

D CONSOLE BACKREST



1PC

E RIGHT BACKREST



1PC

F ADAPTER 2



1PC

HARDWARE IDENTIFICATION

1 WING NUT



2PCS


2 THREADED BOLT

2PCS

ASSEMBLY INSTRUCTION




STEP 1




**BOTTOM VIEW

STEP 2 Turn the Wing nuts (1) clockwise along the Threaded bolts (2) until the Console Backrest (C) is firmly fixed. Connect Power Cables from the Console Backrest (D) to the Seat Body (A).




STEP 3 Rotate the Threaded bolts (2) in a clockwise direction. Thread the wires of the Console Backrest (D) through the hole located on the Console Base (A).



**BACK VIEW

STEP 4




COASTERFURNITURE.COM


ASSEMBLY INSTRUCTION

COASTER


STEP 5



STEP 6





STEP 7 COMPLETE




OPERATING MANUAL














Note: Dimension tolerance ±5%